


TC-D5

*AEP Model
Canadian Model*



STEREO CASSETTE RECORDER

SPECIFICATIONS

Power Requirements: 3 V dc, two batteries IEC designation R20 (size D)
External Power Input Jack
required voltage: 6 V dc
usable from 100, 117, 120 V ac with optional
AC Power Adaptor AC-12, from 110, 120, 127,
220, 240 V ac with optional AC-122, or from
12 V car battery with optional Sony Car
Battery Cord DCC-127A or DCC-130

Battery Life: Approx. 2 hours of continuous recording with
Sony Super Batteries SUM-1S or 5.5 hours
with Eveready Alkaline Batteries No. E95

Dimensions: Approx. 237 (w) x 48 (h) x 168 (d) mm
9 ³/₈ (w) x 1 ⁷/₈ (h) x 6 ⁵/₈ (d) inches

Weight: Approx. 1.7 kg, 3 lb 12 oz
including batteries

Track: 4-track 2-channel stereo

Fast Winding Time: Approx. 150 sec. with Sony Cassette C-60

Frequency Response: DOLBY NR OFF with MICROPHONE inputs

- with Ferri-chrome Cassette
(TAPE SELECT : Fe-Cr)
20 – 18,000 Hz (NAB)
30 – 16,000 Hz $\pm$ 3 dB (NAB)
30 – 16,000 Hz (DIN)
- With Chromium Dioxide Cassette
20 – 16,000 Hz (NAB)
30 – 15,000 Hz $\pm$ 3 dB (NAB)
30 – 15,000 Hz (DIN)

- With standard cassette
(TAPE SELECT : NORMAL)
20 – 15,000 Hz (NAB)
30 – 12,000 Hz (DIN)

Wow and Flutter: 0.06 % (WRMS)
 $\pm$ 0.17 % (DIN)

S/N Ratio: DOLBY NR OFF

- With Ferri-chrome Cassette
(TAPE SELECT : Fe-Cr)
59 dB at peak level (NAB)
57 dB (DIN, 1975 rev.)
- With Chromium Dioxide Cassette
55 dB at peak level (NAB)
- With standard cassette
(TAPE SELECT : NORMAL)
53 dB at peak level (NAB)

DOLBY NR ON
Improved by 5 dB at 1 kHz, 10 dB
above 5 kHz

**Total Harmonic
Distortion:** 1.3 %

**Record Bias
Frequency:** 85 kHz

— Continued on page 2 —

'Dolby' and the double-D symbol are the trade marks of
Dolby Laboratory Inc. Noise reduction system manufactured
under license from Dolby Laboratory Inc.

SONY

SERVICE MANUAL

Speaker: Approx. 5 cm (2 inches) dia.
Power Output: 200 mW (at 10 % harmonic distortion)
at dc operation
Inputs: Two MICROPHONE input jacks (phone jack)
sensitivity 0.2 mV (−72 dB)
for low impedance microphone
Two LINE IN jacks (phono jack)
sensitivity 0.06 V (−22 dB)
input impedance 100 k Ω

Outputs: Two LINE OUT jacks (phono jack)
load impedance 10 k Ω or higher
rated output 0.435 V (−5 dB) at load
impedance 100 k Ω
HEADPHONES jack (stereo binaural jack)
for 8–32 Ω impedance headphones

0 dB = 0.775 V

LOCK DIAGRAM

1-2. MECHANICAL OPERATION

• Disc Drive System

An elastic rubber coating is applied to the flywheel and the motor pulley is pressed directly against this rubber coating to drive the flywheel.

The compliance of this elastic materials and the inertial mass of the flywheel together function as a mechanical filter, to eliminate any flutter components above approximately 100Hz.

Motor torque increases in inverse proportion to the reduction ratio between the motor and the flywheel.

Meanwhile, since the inertial mass of the flywheel itself is low, excellent start-up characteristics (The time from start-up to rated speed is less than 0.2 sec) and anti-rolling effect are obtained.

• Capstan Servo Control Mechanism

The speed is detected through the flywheel which is directly coupled to the capstan, to apply the servo control.

As shown in Fig. 1-1, the bearing assembly comprises a bias magnet, coil, and stator.

The flywheel has a rotor and the coil senses fluctuations in magnetic flux caused by variations in the air gap between the rotor and the stator, to generate the servo control frequencies.

This serves to remove any wow components from 10Hz down to the vicinity of DC, to improve the anti-rolling effect.





Fig. 1-1


SECTION 2 DISASSEMBLY

- Follow the disassembly procedure in the numerical order given.


Top Panel Ass'y Removal




Record Amp Board Removal




4P Phono Jack Removal




Cassette Lid Ass'y and Stabilizer Board Removal




Cassette Frame Removal




Motor Ass'y Removal




Front Panel Ass'y Removal




Chassis Removal




Flywheel Ass'y Removal



Bottom Cover Ass'y Removal



Audio Amp Board Removal



SECTION 3 ADJUSTMENTS


3-1. MECHANICAL ADJUSTMENTS

PRECAUTION

1. Clean the following parts with a denatured-alcohol-moistened swab:
record/playback head pinch roller
erase head rubber belts
capstan idlers
2. Demagnetize the record/playback head with a head demagnetizer.
3. Do not use a magnetized screwdriver for the adjustments.
4. After the adjustments, apply suitable locking compound to the parts adjusted.
5. The adjustments should be performed with the rated power supply voltage unless otherwise noted.


Motor Pressure Measurement — playback mode —

1. Place the set vertically.
2. Push the end of motor with the spring scale as shown. The flywheel will not stop rotating.
3. Measure the pressure of motor against the flywheel when the flywheel starts to rotate, while returning the spring scale slowly.



CrO₂ Tape Detecting Lever Adjustment — stop mode —

1. Insert the tape cassette (except for CrO₂ tape) into the set.
2. Push the CrO₂ tape detecting lever in the direction of the arrow. Make sure that the clearance between the cassette and CrO₂ tape detecting lever is 0.3-0.5mm ($\frac{1}{64}$). If necessary, bend the lever.
3. Make sure that the miniature switch (S902) is turned off when returning the CrO₂ tape detecting lever to the original position.




Torque Measurement

FWD torque	28 - 48 g-cm (0.39 - 0.66 oz-inch)
FF torque	more than 100 g-cm (1.38 oz-inch)
REW torque	more than 70 g-cm (0.96 oz-inch)
Back-tension torque	less than 5 g-cm (0.07 oz-inch)


Pinch Roller Pressure Adjustment — playback mode —

1. Hook the pinch roller with a spring scale.
2. Pull the spring scale.
3. Slowly return the pinch roller and read the spring scale as soon as the pinch roller starts to rotate.




Thrust Adjustment — playback mode —

1. Connect a dc voltmeter across the motor.
2. Turn the screw clockwise for the position where the meter reading suddenly increases.
3. Loosen the screw $\frac{1}{4}$ turn from the position obtained in step 2.



Pause Timing Adjustment — playback mode —

1. Adjust the position of pinch-lever release plate ass'y so that the pinch roller and the take-up reel spindle stop rotating at the same time when depressing the PAUSE button slowly.
2. Make sure that the pinch roller touches the capstan after the take-up reel spindle starts to rotate when the PAUSE button is released.



3-2. ELECTRICAL ADJUSTMENTS

Note: The adjustment should be performed in the order given in this service manual.
The adjustments should be performed for both L-CH and R-CH.

Test Equipment/Tools Required:

audio oscillator (af osc)
VTVM
digital frequency counter
speed checker SONY LFM-30
oscilloscope
attenuator (600Ω)
non-magnetic screwdriver
resistors ... 300Ω (¼W), 10kΩ (¼W),
100kΩ (¼W)
blank tapes (completely erased with bulk eraser)
SONY CS-10 (HF), CS-20 (CrO₂),
CS-30 (Fe-Cr)

Set the TAPE SELECT switch in accordance with the tape used as follows.

Tape	TAPE SELECT switch
CS-10	NORMAL
CS-20	CrO ₂
CS-30	Fe-Cr

SONY test tapes



P-4-A81S (6.3kHz, -10dB)
P-4-L81 (333Hz, 0dB)
WS-48 (3kHz, 0dB)

Switches and controls should be set as follows unless otherwise specified.

DOLBY NR switch: OFF
TAPE SELECT switch: NORMAL
LIMITER switch: OFF
MIC ATT switch: 0 dB

Test Equipment Connections:

Input side:



Standard Record:

Deliver the standard input signal level to the input jack and set the REC LEVEL control to obtain the standard output signal level.

Standard Input Level

	MIC	LINE IN
source impedance	300Ω	10kΩ
input level	0.77mV (-60dB)	0.25V (-10dB)


Standard Output Level

	LINE OUT
load impedance	100kΩ
output level	0.44V (-5dB)

Tape Speed Adjustment

Procedure:

Mode: Playback




Adjust RV701 to obtain the specified values below.

Specification:

Speed checker	Digital frequency counter
-1.0 ~ +1.0%	2,970 ~ 3,030Hz

Adjustment Location:

— audio amp board (conductor side) —




Record/playback Head Azimuth Adjustment


Procedure:

1. Mode: Playback

test tape
P-4-A81S
(6.3kHz, -10dB)




2. Turn the adjustment screw for maximum level and set it to the mechanical mid position between L-CH and R-CH peak positions.




3. Mode: Playback

test tape
P-4-A81S
(6.3kHz, -10dB)




Adjustment Location:



Playback Level Adjustment

Procedure:

1. Mode: Playback




2. Adjust RV401 (L-CH) and RV501 (R-CH) to obtain 0.56V (-3dB) VTVM reading.
3. Make sure that the LINE OUT level does not change when the mode is changed from play-back to stop several times.

Specification:

LINE OUT level: 0.52 – 0.58V
(-3.5 to -2.5dB)

Adjustment Location:


– audio amp board (conductor side) –



Battery Indication Meter Adjustment

Procedure:


1. Mode: Playback (with no cassette installed)
2. Feed 2.2V dc to DC IN 6V jack.
3. When the BATT CHECK/LIGHT button is pushed, adjust RV301 so that the meter indicates the position as shown below.



level meter

Adjustment Location:


– record amp board –




Record Bias Adjustment

Procedure:

1. Mode: Record
TAPE SELECT switch: NORMAL
LIMITER switch: OFF



1. 333Hz, 0.77mV (-60dB)
2. 1kHz, 10kHz, 77μV (-80dB)
2. Feed a signal of 333Hz, 0.77mV (-60dB) into the MIC jack.
3. Adjust the REC LEVEL control for -5dB (0.44V) on the VTVM.
4. Feed the signals of 1kHz and 10kHz, 77μV (-80dB) into the MIC jack.




5. Mode: Playback
recorded portion
6. Play back the signals of 1kHz and 10kHz, and connect the pattern by soldering for specified values. If necessary, connect the two or more patterns.

Specification:

±0.5dB or less (10kHz level deviation from 1kHz)

Adjustment Location:


– audio amp board (conductor side) –




Record Level Adjustment

Procedure:

1. Mode: Standard record (See page 9)
MIC ATT switch: 0dB
LIMITER switch: OFF



2. Mode: Playback




3. Adjust RV402 (L-CH) and RV502 (R-CH) to obtain the specified VTVM reading.

Specification:

Tape	TAPE SELECT switch	LINE OUT level
CS-10	NORMAL	0.40 – 0.45V (-6.0 to -5.0dB)
CS-20	automatically changed to CrO ₂ position.	0.31 – 0.50V (-8.0 to -4.0dB)
CS-30	Fe-Cr	

Adjustment Location:


– audio amp board (Conductor Side) –




Record Bias Adjustment

Procedure:

- Mode: Record
TAPE SELECT switch: NORMAL
LIMITER switch: OFF



- Feed a signal of 333Hz, 0.77mV (-60dB) into the MIC jack.
- Adjust the REC LEVEL control for -5dB (0.44V) on the VTVM.
- Feed the signals of 1kHz and 10kHz, 77μV (-80dB) into the MIC jack.




- Play back the signals of 1kHz and 10kHz, and connect the pattern by soldering for specified values. If necessary, connect the two or more patterns.

Specification:

±0.5dB or less (10kHz level deviation from 1kHz)

Adjustment Location:


— audio amp board (conductor side) —




Record Level Adjustment

Procedure:

- Mode: Standard record (See page 9)
MIC ATT switch: 0dB
LIMITER switch: OFF



- Mode: Playback




- Adjust RV402 (L-CH) and RV502 (R-CH) to obtain the specified VTVM reading.

Specification:

Tape	TAPE SELECT switch	LINE OUT level
CS-10	NORMAL	0.40 - 0.45V (-6.0 to -5.0dB)
CS-20	automatically changed to CrO ₂ position.	0.31 - 0.50V (-8.0 to -4.0dB)
CS-30	Fe-Cr	

Adjustment Location:


— audio amp board (Conductor Side) —




Level Meter Calibration

Procedure:

- Mode: Standard record (See page 9)
MIC ATT switch: 0dB
LIMITER switch: OFF




- Make sure that the VTVM reads 0.44V (-5dB).
- Adjust RV101 (L-CH) and RV201 (R-CH) for specified reading on the level meter.



level meter

Adjustment Location:


— record amp board —



MPX Filter Adjustment

Procedure:

- Mode: Record
- Feed a signal of 333Hz, 0.25V (-10dB) into the LINE IN jack.
- Adjust the REC LEVEL control for -5dB (0.44V) on the VTVM.
- Feed a signal of 19kHz, 0.25V (-10dB) into the LINE IN jack.
- Adjust L102 (L-CH) and L202 (R-CH) for minimum reading on the VTVM.




Specification:

23dB or more (level difference between 333Hz and 19kHz)

Adjustment Location:


— record amp board —




L102 (L-CH)

L202 (R-CH)


Replacement Semiconductors:
(See page 20)



• DC resistance measurements are with coils and transformers connected on the circuit board, and are approximate.







Note:

- All capacitors are in μF unless otherwise noted. $\text{pF} : \mu\text{F}$ 50WV or less are not indicated except for electrolytics.
- All resistors are in ohms, $\frac{1}{2}\text{W}$ unless otherwise noted. $\text{k}\Omega : 1000\Omega$, $\text{M}\Omega : 1000\text{k}\Omega$
- All adjustable resistors have characteristic curve B, unless otherwise noted.
- : panel designation.
- : adjustment for repair.
- : B+ bus.
- : B- bus.
- Voltages are dc with respect to ground unless otherwise noted.
- Readings are taken under no signal conditions with a VOM ($20\text{k}\Omega/\text{V}$).
- Voltage variations may be noted due to normal production tolerances.


: Measured by using a VTVM
 [] : in record mode
 () : in FF or REW mode
 { } : When S905 (LIMITER) is set to ON.
 (()) : When S902 (CrO_2) is off and S903 (TAPE SELECT) is set to Fr- O_2 in record mode.

no mark: in playback mode

The total current is taken with no cassette installed.
























- Switch

Ref. No.	Switch	Position
S301	MIC ATT	0 dB
S601	REC/PB	PB
S901	BATT CHECK/LIGHT	OFF
S902	CrO ₂	OFF
S903	TAPE SELECT	NORMAL
S904	DOLBY NR	OFF
S905	LIMITER	OFF
S906	POWER	ON
S907	FWD	OFF
S908	REC-PB/MUTE	OFF




Replacement Semiconductors


For replacement, use semiconductors except in ().

Q101, 102, 201, 202, 401, 402 Q404, 411, 501, 502, 504, 511 2SC1362 (2SC632A) 	IC302: BX336  (Marking side view)	IC303: BX338  (Marking side view)	D801: 10E2 (10E1) 
	IC304: BX335  (Marking side view)	IC401, 501: TA7122AP 	D901, 902 SLP24B 
Q103, 203, 302, 403, 405-410 Q412-416, 503, 505-510, 512-516 Q601-603, 605-607 Q609, 701, 703, 705, 706 Q801, 803-805 2SC1364 (2SC634A) 	IC701: μPC4558C  (Top view)	IC702: CX065A 	Q704: 2SK43-4 (2SK43-3) 
	IC801: CX184 	RM701: DM101 	
Q104: 2SC1859 Q204: 2SC1859 	Q301: 2SC1474 (2SC1474-3) 	D101, 201 D102, 202 1T22AM (1T22) 	D301, 404, 504 D601, 602, 701 1S1555 (1T40) 
Q604, 608, 702 2SA678 	Q802: 2SA772-14 (2SA772) 	D401, 402, 501, 502 1T22AM (1T22A) 	D403, 503: 1S1555 
Q901: 2SA861 (2SA861-3) 	IC301: BX337  (Marking side view)		

SECTION 5
EXPLODED VIEWS




- Note:**
- Items with no part number and/or no description are not stocked because they are seldom required for routine service.
 - All screws are Phillips (cross recess) type unless otherwise noted.
(-) = slotted head
 - Circled letters (A) to (Z) are applicable to European models only.



Note:


- Items with no part number and/or no description are not stocked because they are seldom required for routine service.
- All screws are Phillips (cross recess) type unless otherwise noted.
- (-) = slotted head
- Circled letters (A to Z) are applicable to European models only.

5-4.

**Note:**

- Items with no part number and/or no description are not stocked because they are seldom required for routine service.
- All screws are Phillips (cross recess) type unless otherwise noted.
(-) = slotted head
- Circled letters (A) to (Z) are applicable to European models only.

5-5.



Note:

- Items with no part number and/or no description are not stocked because they are seldom required for routine service.
- All screws are Phillips (cross recess) type unless otherwise noted.
- Circled letters (A) to (Z) are applicable to European models only.

A

B

C

D

5-6.

1

2

3

4

5

X-3545-521-0 (B)
Pulley Ass'y, FWD

3-701-437-01 (A)
Washer, plastic; 2mm dia (t0.13)

▲5
3-545-696-0 (A)
Washer, plastic; 1.2mm dia

3-545-601-00 (B)
Belt, intermediate pulley

3-701-436-01 (A)
Washer, plastic; 1.6mm dia (t0.13)

▲2
3-545-542-00 (B)
Spring

▲6
X-3556-218-0 (B)
Pulley Ass'y, intermediate

X-3545-533-0 (B)
Lever (B) Ass'y, FWD

▲7
X-3556-230-0 (F)
Reel Spindle Ass'y

▲3
3-545-606-00 (A)
Gear

3-701-437-01 (A)
Washer, plastic; 2mm dia (t0.13)

▲4
3-545-696-0 (A)
Washer, plastic; 1.2mm dia

X-3556-226-0 (I)
Lever Ass'y, shut-off
including parts marked ▲1 - 7

X-3545-512-0
Lever (A) Ass'y, FWD

3-527-188-00 (A)
Spring

▲1
3-515-141-00 (B)
Reel Spindle, take-up

3-527-028-00 (A)
Lining, brake

3-527-028-00 (A)
Lining, brake

3-701-439-21 (A)
Washer, plastic; 3mm dia (t0.5)

Lever Ass'y, brake

Steel Ball, 2mm dia

3-701-436-11 (A)
Washer, plastic; 1.6mm dia (t0.25)

3-507-115-00 (B)
Belt (A)

X-3556-217-0 (B)
Pulley Ass'y, REW

3-701-436-01 (A)
Washer, plastic; 1.6mm dia (t0.13)

7-627-553-37
P2 x 3

3-545-508-00 (A)
Spacer

X-3556-223-0 (B)
Lever (B) Ass'y, REW

Lever (B), shut-off

E1.5

E1.2

3-527-193-00 (A)
Spring

3-545-602-00 (B)
Belt, counter

3-556-290-00 (A)
Bushing

3-556-280-00 (A)
Roller

3-545-721-00 (B)
Pulley, supply reel spindle

Chassis Ass'y

X-3556-221-0 (B)
Lever (A) Ass'y, REC

7-627-553-47
P2 x 4


3-515-141-00 (B)
Cap, supply reel spindle

3-527-193-00 (A)
Spring

Note:

- Items with no part number and/or no description are not stocked because they are seldom required for routine service.
- All screws are Phillips (cross recess) type unless otherwise noted.
(-) = slotted head
- Circled letters (A) to (Z) are applicable to European models only.

5-7.



Note:

- Items with no part number and/or no description are not stocked because they are seldom required for routine service.
- All screws are Phillips (cross recess) type unless otherwise noted.
(-) = slotted head
- (□□T) shows the number of coils in spring.
- Circled letters (A to Z) are applicable to European models only.

• Circled letters (**A** to **Z**) are applicable to European models only.

SECTION 6 ELECTRICAL PARTS LIST

Ref. No. Part No. Description

SEMICONDUCTORS

Transistors

⇒ Q101, 201 Q102, 202	8-729-665-47	(B)	2SC1362
⇒ Q103, 203	8-729-663-47	(B)	2SC1364
Q104, 204	8-765-052-20	(B)	2SC1859
⇒ Q301	8-760-335-10	(B)	2SC1474
⇒ Q302	8-729-663-47	(B)	2SC1364
⇒ Q401, 501 Q402, 502	8-729-665-47	(B)	2SC1362
⇒ Q403, 503	8-729-663-47	(B)	2SC1364
⇒ Q404, 504	8-729-665-47	(B)	2SC1362
⇒ Q405-410 Q505-510	8-729-663-47	(B)	2SC1364
⇒ Q411, 511	8-729-665-47	(B)	2SC1362
⇒ Q412-416 Q512-516	8-729-663-47	(B)	2SC1364
⇒ Q601-603	8-729-663-47	(B)	2SC1364
Q604	8-727-788-00	(B)	2SA678
⇒ Q605-607	8-729-663-47	(B)	2SC1364
Q608	8-727-788-00	(B)	2SA678
⇒ Q609, 701	8-729-663-47	(B)	2SC1364
Q702	8-727-788-00	(B)	2SA678
⇒ Q703	8-729-663-47	(B)	2SC1364
⇒ Q704	8-723-304-00	(B)	2SK43-4
⇒ Q705, 706 Q801	8-729-663-47	(B)	2SC1364
⇒ Q802	8-760-514-10	(B)	2SA772-14
⇒ Q803-805	8-729-663-47	(B)	2SC1364
⇒ Q901	8-763-213-00	(C)	2SA861

Diodes

⇒ D101, 201 D102, 202	8-719-422-21	(A)	1T22AM
⇒ D301	8-719-815-55	(A)	1S1555

Ref. No. Part No. Description

⇒ D401, 501 D402, 502	8-719-422-21	(A)	1T22AM
D403, 503	8-719-815-55	(A)	1S1555
D404, 504	8-719-815-55	(A)	1S1555
⇒ D601, 602 D701			

⇒ D801	8-719-200-02	(B)	10E2
D901, 902	8-719-900-24	(B)	SLP24B
RM701	8-745-101-01	(C)	DM101

ICs

IC301	8-743-370-00	(I)	BX337
IC302	8-743-360-00	(G)	BX336
IC303	8-743-380-00	(F)	BX338
IC304	8-743-350-00	(H)	BX335
IC401, 501	8-759-271-22	(C)	TA7122AP
IC701	8-759-145-58	(D)	μPC4558C
IC702	8-759-600-65	(D)	CX065A
IC801	8-751-840-00	(F)	CX184

Thermistor

⇒ Th801	1-800-198-XX	(C)	S-1000
---------	--------------	-----	--------

COILS

L101, 201	1-407-879-00	(B)	33mH, microinductor
L102, 202	1-407-938-00	(B)	27mH, variable
L401, 501	1-407-212-XX	(B)	33mH, microinductor
L402, 502	1-407-204-XX	(B)	6.8mH, microinductor
L403, 503	1-407-207-XX	(B)	12mH, microinductor

TRANSFORMERS

T401, 501	1-427-448-00	(C)	Output
T601	1-433-200-00	(B)	Bias Oscillator

⇒ : Due to standardization, interchangeable replacements may be substituted for parts specified in the diagrams.

- Circled letters (**A** to **Z**) are applicable to European models only.

<u>Ref. No.</u>	<u>Part No.</u>	<u>Description</u>			
CAPACITORS					
All capacitors are in μ F and tantalum unless otherwise noted. 50WV or less are not indicated except for electrolytics and tantalum. pF : μ F, elect : electrolytic					
C101, 201	1-131-420-11	(B)	4.7	10V	
C102, 202	1-102-074-11	(A)	0.001		ceramic
C103, 203 C104, 204	1-131-345-11	(B)	0.47	35V	
C105, 205	1-102-074-11	(A)	0.001		ceramic
C106, 206	1-131-377-11	(B)	10	10V	
C107, 207	1-102-971-11	(A)	82p		ceramic
C108, 208	1-161-042-11	(A)	0.0018		ceramic (semiconductor)
C109, 209	1-161-039-11	(A)	0.001		ceramic (semiconductor)
C110, 210	1-108-569-12	(A)	0.0038		mylar
C111, 211	1-108-230-12	(A)	0.0022		mylar
C112, 212	1-131-392-11	(B)	33	3.15V	
C113, 213	1-131-377-11	(B)	10	10V	
C114-117 C214-217	1-131-408-11	(B)	1	35V	
C118, 218 C119, 219	1-102-973-11	(A)	100p		ceramic
C301-303	1-121-414-11	(A)	100	10V	elect
C304	1-121-979-11	(A)	47	6.3V	elect
C305	1-131-392-11	(B)	33	3.15V	
C306	1-131-414-11	(B)	2.2	20V	
C307	1-102-074-11	(A)	0.001		ceramic
C308	1-131-392-11	(B)	33	3.15V	
C401, 501	1-102-112-11	(A)	330p		ceramic
C402, 502	1-131-420-11	(B)	4.7	10V	
C403, 503	1-131-377-11	(B)	10	10V	
C404, 504	1-101-888-11	(A)	68p		ceramic
C405, 505	1-102-074-11	(A)	0.001		ceramic
C406, 506	1-131-420-11	(B)	4.7	10V	
C407, 507	1-108-589-12	(A)	0.027		mylar
C408, 508	1-131-420-11	(B)	4.7	10V	
C409, 509	1-108-355-12	(A)	0.0056		mylar
C410, 510	1-131-414-11	(B)	2.2	20V	
C411, 511	1-102-074-11	(A)	0.001		ceramic

<i>Ref. No.</i>	<i>Part No.</i>	<i>Description</i>	
C412, 512	1-131-393-11	B 47	3.15V
C413, 513	1-101-888-11	A 68p	ceramic
C414, 514	1-131-387-11	B 47	6.3V
C415, 515	1-108-232-12	A 0.0033	mylar
C416, 516	1-131-377-11	B 10	10V
C417, 517	1-108-581-12	A 0.012	mylar
C418, 518	1-108-579-12	A 0.01	mylar
C419, 519	1-108-361-12	A 0.056	mylar
C420, 520	1-108-355-12	A 0.0056	mylar
C421, 521	1-102-953-11	A 18p	ceramic
C422, 522	1-131-377-11	B 10	10V
C423, 523	1-108-232-12	A 0.0033	mylar
C424, 524	1-131-414-11	B 2.2	20V
C425, 525	1-108-234-12	A 0.0047	mylar
C426, 526	1-131-417-11	B 3.3	16V
C427, 527	1-131-377-11	B 10	10V
C428, 528	1-102-074-11	A 0.001	ceramic
C429, 529 C430, 530	1-131-420-11	B 4.7	10V
C431, 531	1-102-937-11	A 4p	ceramic
C432, 532	1-102-074-11	A 0.001	ceramic
C433, 533	1-131-395-11	B 100	3.15V
C434, 534	1-131-420-11	B 4.7	10V
C435, 535	1-131-341-11	B 0.1	35V
C436, 536	1-131-346-11	B 0.68	35V
C437, 537	1-102-115-11	A 560p	ceramic
C438, 538	1-107-169-11	A 100p	500V silvered mica
C439, 539	1-108-581-12	A 0.012	mylar
C440, 540	1-108-579-12	A 0.01	mylar
C441, 541 C442, 542	1-108-360-12	A 0.039	mylar
C443, 543	1-131-345-11	B 0.47	35V
C444, 544	1-131-393-11	B 47	3.15V
C445, 545	1-107-042-11	A 2.2p	500V silvered mica
C446, 546	1-107-253-11	B 15+18+22+27p	500V silvered mica
C601	1-121-651-11	A 10	16V elect
C602-605	1-131-420-11	B 4.7	10V
C606, 607	1-108-373-12	A 0.0047	100V mylar
C608	1-108-579-12	A 0.01	mylar

- Circled letters (**A** to **Z**) are applicable to European models only.

<i>Ref. No.</i>	<i>Part No.</i>	<i>Description</i>			
C609	1-129-708-11	A 0.0033	630V	film	
C610	1-131-414-11	B 2.2	20V		
C611, 612	1-121-419-11	A 220	6.3V	elect	
C613	1-121-940-11	B 470	16V	elect	
C701	1-161-013-11	A 0.01		ceramic	
				(semiconductor)	
C702	1-131-377-11	B 10	10V		
C703	1-102-115-11	A 560p		ceramic	
C704	1-131-341-11	B 0.1	35V		
C705	1-131-380-11	B 33	10V		
C706	1-131-414-11	B 2.2	20V		
C707	1-161-045-11	A 0.0033		ceramic	
				(semiconductor)	
C708	1-131-414-11	B 2.2	20V		
C709	1-131-395-11	B 100	3.15V		
C710	1-161-045-11	A 0.0033		ceramic	
				(semiconductor)	
C711	1-130-140-11	B 0.039	100V	film	
C712	1-102-112-11	A 330p		ceramic	
C713	1-131-211-11	B 0.22	35V		
C714-716	1-161-045-11	A 0.0033		ceramic	
				(semiconductor)	
C717	1-131-380-11	B 33	10V		
C718	1-131-374-11	B 33	16V		
C801	1-102-074-11	A 0.001		ceramic	
C802	1-131-377-11	B 10	10V		
C803	1-131-408-11	B 1	35V		
C804	1-131-345-11	B 0.47	35V		
C805	1-131-380-11	B 33	10V		
C807, 808	1-161-019-11	A 0.033		ceramic	
				(semiconductor)	
C809	1-161-045-11	A 0.0033		ceramic	
				(semiconductor)	
C901	1-102-074-11	A 0.001		ceramic	

<i>Ref. No.</i>	<i>Part No.</i>	<i>Description</i>			
-----------------	-----------------	--------------------	--	--	--

RESISTORS

All resistors are in ohms. Common 1/4W carbon resistors are omitted. Refer to the list on page 32 for their resistance values. (k Ω : 1000 Ω , M Ω : 1000k Ω)

R703, 704	1-209-781-11	A 10k	1/16W	carbon
R705	1-210-840-11	A 220k	1/16W	carbon
R707	1-210-384-11	A 47k	1/16W	carbon
R708	1-204-122-11	A 1k	1/16W	micro
R709	1-210-844-11	A 470k	1/16W	carbon
R713	1-214-169-11	A 36k	1/4W	metal oxide
R801	1-204-122-11	A 1k	1/16W	carbon
R802	1-210-355-11	A 100	1/16W	carbon
R806	1-204-122-11	A 1k	1/16W	carbon
R807	1-209-777-11	A 6.8k	1/16W	carbon
R808	1-209-770-11	A 2.7k	1/16W	carbon
R809	1-209-771-11	A 3.9k	1/16W	carbon
R810	1-210-840-11	A 220k	1/16W	carbon
R811	1-210-388-11	A 68k	1/16W	carbon
R812	1-204-122-11	A 1k	1/16W	carbon
RV101,201	1-224-252-XX	B 10k-B, adjustable;	METER LEVEL	
RV301	1-224-254-XX	B 47k-B, adjustable;	BATTERY INDICATION	
RV401,501	1-224-252-XX	B 10k-B, adjustable;	PB LEVEL	
RV402,502	1-224-252-XX	B 10k-B, adjustable;	REC LEVEL	
RV701	1-226-274-00	C 20k-B, adjustable;	TAPE SPEED	
RV901	1-226-273-00	E 20k-A, variable;	REC LEVEL	
RV902	1-226-272-00	D 20k-B, variable;	MONITOR LEVEL	

SWITCHES

S301	1-516-846-00	B Slide, MIC ATT
S601	1-514-254-00	C Slide, REC/PB
S901	1-514-346-00	B Leaf, BATTERY CHECK/LIGHT
S902	1-552-478-00	C Miniature, CrO ₂
S903-905	1-552-477-00	C Lever-slide; TAPE SELECT, DOLBY NR, LIMITER
S906-908	1-514-346-00	B Leaf, POWER, FWD, rec-pb/mute

Note: Circled letters (**A** to **Z**) are applicable to European models only.

Ref. No. Part No. Description

JACKS

CNJ901 1-507-59 3-00 **B** LINE IN, LINE OUT
 CNJ902 1-507-44 7-XX **B** DC IN
 J901, 902 1-507-42 1-00 **C** MICROPHONE
 J903 1-507-47 7-XX **D** HEADPHONES

MISCELLANEOUS

CP601 1-464-08 1-00 **L** DC-DC Converter
 HE901 8-825-69 2-10 **E** Head, erase; EF168-36A
 HRP901 8-825-584-00 **M** Head, record/playback; PF145-3602A
 M901 X-3556-2 35-1 **T** Motor Ass'y
 ME901 1-520-35 0-00 **H** Meter, level (LEFT)

 ME902 1-520-35 1-00 **H** Meter, level (RIGHT)
 PL901 1-518-134-XX **B** Lamp 100mA/2V
 SP901 1-502-582-00 **G** Speaker
 1-452-130-00 **B** Magnet

ACCESSORIES & PACKING MATERIALS

<u>Part No.</u>	<u>Description</u>
X-3556-236-0	G Belt Ass'y, carrying
X-3701-105-0	A Tip Ass'y, head cleaning
1-528-022-00	B Battery, size "D" (Canadian model)
1-534-049-31	E Cord, connection; RK-74H
3-557-850-00	B Cushion
3-557-852-00	D Carton
3-701-625-00	A Bag, plastic
3-701-631-00	A Bag, plastic
3-770-516-11	E Manual, instruction
3-793-828-11	A Card, caution
3-793-956-31	B Card, warranty (Canadian model)

1/4 WATT CARBON RESISTORS (A) Note: Circled letter (A) is applicable to European models only.

Ω	Part No.	Ω	Part No.	Ω	Part No.	Ω	Part No.	Ω	Part No.	Ω	Part No.	Ω	Part No.
1.0	1-244-601-11	10	1-244-625-11	100	1-244-649-11	1.0k	1-244-673-11	10k	1-244-697-11	100k	1-244-721-11	1.0M	1-244-745-11
1.1	1-244-602-11	11	1-244-626-11	110	1-244-650-11	1.1k	1-244-674-11	11k	1-244-698-11	110k	1-244-722-11	1.1M	1-244-746-11
1.2	1-244-603-11	12	1-244-627-11	120	1-244-651-11	1.2k	1-244-675-11	12k	1-244-699-11	120k	1-244-723-11	1.2M	1-244-747-11
1.3	1-244-604-11	13	1-244-628-11	130	1-244-652-11	1.3k	1-244-676-11	13k	1-244-700-11	130k	1-244-724-11	1.3M	1-244-748-11
1.5	1-244-605-11	15	1-244-629-11	150	1-244-653-11	1.5k	1-244-677-11	15k	1-244-701-11	150k	1-244-725-11	1.5M	1-244-749-11
1.6	1-244-606-11	16	1-244-630-11	160	1-244-654-11	1.6k	1-244-678-11	16k	1-244-702-11	160k	1-244-726-11	1.6M	1-244-750-11
1.8	1-244-607-11	18	1-244-631-11	180	1-244-655-11	1.8k	1-244-679-11	18k	1-244-703-11	180k	1-244-737-11	1.8M	1-244-751-11
2.0	1-244-608-11	20	1-244-632-11	200	1-244-656-11	2.0k	1-244-680-11	20k	1-244-704-11	200k	1-244-728-11	2.0M	1-244-752-11
2.2	1-244-609-11	22	1-244-633-11	220	1-244-657-11	2.2k	1-244-681-11	22k	1-244-705-11	220k	1-244-729-11	2.2M	1-244-753-11
2.4	1-244-610-11	24	1-244-634-11	240	1-244-658-11	2.4k	1-244-682-11	24k	1-244-706-11	240k	1-244-730-11	2.4M	1-244-754-11
2.7	1-244-611-11	27	1-244-635-11	270	1-244-659-11	2.7k	1-244-683-11	27k	1-244-707-11	270k	1-244-731-11	2.7M	1-244-755-11
3.0	1-244-612-11	30	1-244-636-11	300	1-244-660-11	3.0k	1-244-684-11	30k	1-244-708-11	300k	1-244-732-11	3.0M	1-244-756-11
3.3	1-244-613-11	33	1-244-637-11	330	1-244-661-11	3.3k	1-244-685-11	33k	1-244-709-11	330k	1-244-733-11	3.3M	1-244-757-11
3.6	1-244-614-11	36	1-244-638-11	360	1-244-662-11	3.6k	1-244-686-11	36k	1-244-710-11	360k	1-244-734-11	3.6M	1-244-758-11
3.9	1-244-615-11	39	1-244-639-11	390	1-244-663-11	3.9k	1-244-687-11	39k	1-244-711-11	390k	1-244-735-11	3.9M	1-244-759-11
4.3	1-244-616-11	43	1-244-640-11	430	1-244-664-11	4.3k	1-244-688-11	43k	1-244-712-11	430k	1-244-736-11	4.3M	1-244-760-11
4.7	1-244-617-11	47	1-244-641-11	470	1-244-665-11	4.7k	1-244-689-11	47k	1-244-713-11	470k	1-244-737-11	4.7M	1-244-761-11
5.1	1-244-618-11	51	1-244-642-11	510	1-244-666-11	5.1k	1-244-690-11	51k	1-244-714-11	510k	1-244-738-11	5.1M	1-244-762-11
5.6	1-244-619-11	56	1-244-643-11	560	1-244-667-11	5.6k	1-244-691-11	56k	1-244-715-11	560k	1-244-739-11		
6.2	1-244-620-11	62	1-244-644-11	620	1-244-668-11	6.2k	1-244-692-11	62k	1-244-716-11	620k	1-244-740-11		
6.8	1-244-621-11	68	1-244-645-11	680	1-244-669-11	6.8k	1-244-693-11	68k	1-244-717-11	680k	1-244-741-11		
7.5	1-244-622-11	75	1-244-646-11	750	1-244-670-11	7.5k	1-244-694-11	75k	1-244-718-11	750k	1-244-742-11		
8.2	1-244-623-11	82	1-244-647-11	820	1-244-671-11	8.2k	1-244-695-11	82k	1-244-719-11	820k	1-244-743-11		
9.1	1-244-624-11	91	1-244-648-11	910	1-244-672-11	9.1k	1-244-696-11	91k	1-244-720-11	910k	1-244-744-11		

HARDWARE NOMENCLATURE

Screw:

— P 3 x 10


L: Length in mm

D: Diameter in mm

Type of head

Indicated slotted-head only.

Unless otherwise indicated, it means cross-recessed head (Phillips type).



Nut, Washer, Retaining ring:

N 3

Diameter of usable screw or shaft

Reference designation



Reference Designation	Shape	Description	Remarks
SCREWS			
P		pan-head screw	binding-head (B) screw for replacement
PWH		pan-head screw with washer face	binding-head (B) screw and flat washer for replacement
PS PSP		pan-head screw with spring washer	binding-head (B) screw and spring washer for replacement
PSW PSPW		pan-head screw with spring and flat washers	binding-head (B) screw and spring and flat washers for replacement
R		round-head screw	binding-head (B) screw for replacement
K		flat-countersunk-head screw	
RK		oval-countersunk-head screw	
B		binding-head screw	
T		truss-head screw	binding-head (B) screw for replacement
F		flat-fillister-head screw	
RF		fillister-head screw	
BV		braizer-head screw	

Reference Designation	Shape	Description	Remarks
SELF-TAPPING SCREWS			
TA		self-tapping screw	ex: TA, P 3 x 10
PTP		pan-head self-tapping screw	binding-head self-tapping (TA, B) screw for replacement
PTPWH		pan-head self-tapping screw with washer face	binding-head self-tapping (TA, B) screw and flat washer for replacement
PTTWH		pan-head thread-rolling screw with washer face	binding-head (B) screw and flat washer for replacement
SET SCREWS			
SC		set screw	
SC		hexagon-socket set screw	ex: SC 2.6 x 4, hexagon socket
NUT			
N		nut	
WASHERS			
W		flat washer	
SW		spring washer	
LW		internal-tooth lock washer	ex: LW3, internal
LW		external-tooth lock washer	ex: LW3, external
RETAINING RINGS			
E		retaining ring	
G		grip-type retaining ring	